



GTV-580

Quick Start Guide


Version 1.1




Accessories




GTV-580 Main Unit




Mount




USB cable



DC charger



AC adapter




DVB-T
Antenna(Reference)



Remote control




SD card (optional)




DVB-T module




Quick Guide



CD or DVD (user manual, driver, Application, map data...)



AV-OUT cable




SD PULL Label


Note:

1. If any item is missing or damaged, please contact with your local retailer.
2. Fittings graphic presentation can as material object slightly the getting more different, please by fittings not enclosed not real as the accurate.

Overview




Front View	
❶ Power LED	Solid Red – Battery is lower than 40%. Solid Amber – Battery is being charged. Solid Green – Battery full charged.
❷ Volume up	Volume up button.
❸ Menu button	Press the Menu button to go directly to Main Menu of the application.
❹ Volume down	Volume down button.
❺ Microphone	Microphone is enabled when you connect GTV-580 with your Bluetooth cell phone.




Side View and Top View

❶ Power /Mute button	Power (Long Push>2 sec): Turn on the GTV-580, press it again to turn it off (enter the standby mode).
	Mute (Short Push<2 sec): Press to mute the audio, press again to resume.
❷ Clip groove	For the cradle to clip tight to the main unit.
❸ SD card slot	The Navigation software, map data and other media files can be stored in the SD card.
❹ Earphone jack	Plug the earphone or headset to the socket, you can listen to the navigation voice guide or enjoy your favorite music.
❺ Mini USB port	Connect the GTV-580 to PC via an USB cable for data transfer.
❻ Reset button	Use the stylus tip to press down the reset button through the hole to reset the system.



Bottom View and Rear View

①	External Antenna connector	For you to connect an optional MMCX-type external antenna.
②	Speaker	For output the music or navigation voice.
③	Battery Slide Switch	<p>Slide the switch to "OFF" position to prevent from accidentally turning on the device by touching the power button. If you want to use this device, be sure to slide the switch to the "ON" position.</p> <p>❶ The purpose of the Battery Slide Switch is to cut off power to the unit. It is used to disable the unit in transit from the factory and if the unit will be in storage for long periods of time. Be sure that the switch is in the "ON" position when you remove the unit from the box. The GTV-580 will NOT charge if the switch is in the "OFF" position.</p>
④	Charging connector	For power supply and battery charging.
⑤	Docking connector	Docking connector for DVB-T module.




DVB-T module		
①	DVB-T Antenna connector	For you to connect to DVB-T antenna. (on both sides)
②	Charging connector	For power supply and battery charging.
③	Infrared sensor	Infrared sensor for receiving signal from remote control.
④	Docking connector	Docking connector for DVB-T module.
⑤	Clip hook	For clip into the groove of the main unit.
⑥	DVB-T LED	The blue LED will light when DVB-T function is operating.
⑦	AV-OUT	Plug the AV cable into the socket, you can output the DTV displaying to the external monitor when you watch DTV.

Before you start to use the GTV-580, please connect it with the AC adapter and plug to power socket for battery charging. When it is in charging, the status indicator will be amber. If the battery is fully charged, the status indicator will be lit on green.


Download Application Software to memory card by card reader

Insert the SD card into your card reader which is connected to your PC. Insert the CD/DVD into the CD/DVD-ROM drive; the installation program will automatically start. (If your autorun feature is disabled, please manually execute this program by double click the **"auto.exe"** from the root directory of CD/DVD.) Click **"Make System Disk"** button for downloading the application and map into SD card.



Click on the drive letter which your SD card is inserted, and click on **"Start"** button. After the download process is finished, please remove the SD card from card reader, insert it into your GTV-580 and restart it.

Attach GTV-580 to Cradle (DVB-T module)



Release



Lock



1. Place the GTV-580 at a downward angle into the base of the cradle.
 2. Align three grooves and docking connector to push down GTV-580 inward until the top clip locks into place.
 3. Clean windshield glass thoroughly with glass cleaner.
 4. Moisten suction cup and attach mount to the windshield.
 5. Lock mount lever by moving forward.
- To release, bring lever back and pull on the suction cup's clear tab to release suction. Never pull on mounting arm to remove from glass.
 - It is suggested that you attach the mount in the appropriate place in your car. Do not mount in front of an airbag panel, or block the driver's vision.



Charging your GTV-580

Plug the end of AC adapter or DC charger into the charging connector of GTV-580 or DVB-T module. The power LED will light. When battery is fully charged, the LED becomes green.




SD card sticker

Pastes SD PULL LABEL on the SD CARD.










So then may in GTV-580 take out SD CARD by the arrow direction.



Application Main Screen



Main Screen

 Navigation	Tap on the Navigation icon to start the Navigation application.
 TV	Tap on the TV icon to start the DVBT function.
 HandsFree	Tap on the HandsFree icon to start the Bluetooth HandsFree application.
 Media	Tap on the Media icon to enter the sub-screen which contains the music player and photo viewer.
 Setup	Tap on the Setup icon to enter the sub-screen which you can do the settings of the device.
 2007/01/01 12:03	Tap this icon to set the date and time.
	Tap on the battery icon on top right corner of screen; it enters the power setting screen.